

USER MANUAL

Heat presses Transmatic TS 2P/3 P / TS 5 P / TS 5 PA



Original Manual in English !
To keep for future purpose !

Stand: 21/07/2016
Version: 01

DICHIARAZIONE DI CONFORMITA'
DECLARATION OF CONFORMITY
KONFORMITAETSERKLAERUNG
DECLARATION DE CONFORMITE
DECLARACION DE CONFORMIDAD

according to 2006/42/CE e successivi emendamenti

Nome del produttore: **TRANSMATIC SRL**

Manufacturer's name:

Name des Herstellers:

Nom du fabricant:

Nombre del fabricante:

Indirizzo del produttore: **VIA ENZO FERRARI**

Manufacturer's address: **LAZZATE (MB) ITALY**

Adresse des Herstellers:

Adresse du fabricant:

Dirección del fabricante:

dichiara che il prodotto: declares that the product: erklart, dass das Product:
déclare que ce produit: declara, que el material:

Nome del prodotto **Pressa pneumatica**

Product name **Pneumatic presse**

Nom du produit **Presse pneumatique**

MOD. TS

N.

é conforme alle seguenti specifiche: conform to the following product specif:
Folgenden Produktspezifikationen entspricht: est conforme aux specifications suivantes:
es conforme con las siguientes especificaciones:

Low Voltage Directive 2006/95 CEE

EMC Directive 89/336/EEC compatibilità elettromagnetica 2004/108 CE

CEE EN 60-204

EN 60898-1:2003+A1:2004+A11:2005+A12:2008+A13:2012

EN 61000-6-2:2005; EN 61000-6-3:2007

Direttiva 2006/42/CE e successivi emendamenti

Maschinenrichtlinie 2006/42/EG

Lazzate, MARZO 2017

PIETRO ALBANESE


AMMINISTRATORE UNICO

il fascicolo tecnico, come previsto dalla direttiva 2006/42 è costituito e custodito presso
TRANSMATIC SRL - VIA ENZO FERRARI, 11 - 20824 LAZZATE (MB)

INTRODUCTION


ARTICLE

This manual and instruction for use describes following articles :




TS 3 P

1 Working table
Manual swing



TS 5 P

2 Working tables
Manual swing



TS 5 PA

2 Working tables
Automatic swing

ADVISE !



The starting graphic shows the model TS5 P.

GENERAL INFORMATION

This user manual must be at all times available to the operators and the service team of the machine.

The owner of this machine must make sure that the operators, service, and maintenance team have available the fault finding chart and that all work is carried out by competent staff. This manual will help you:

- to understand the use of the machine
- to use the machine properly
- to extend the life time of the machine

The change of the power cable has to be effected by qualified or trained persons in order to avoid injury

Please read this manual carefully. It contains important information in order to use the machine safely and efficiently.

The operation of this machine in compliance of the manual will assure :

- The safety of the operating personal and the avoidance of working accidents.

Transmatic Srl. assumes no liability of damage or malfunctions resulting from failure to observe this manual

Power cables and pneumatic pipes are to be connected properly in order to avoid tripping hazards.

The machine must be placed on a flat (No slope) surface with sufficient structural strength.

WARRANTY AND LIABILITY

The present operating and maintenance manual was written with utmost care. All information and instructions for operations and maintenance is written while taking into account our experience and knowledge in good faith. This operating and maintenance instruction corresponds with text and illustrations from recent technical information. The contents of the manual lay no claims by the purchaser. If you note any omissions and or errors, we ask you in your own interest to inform us about it, for correction.

The time of the warranty of this machine is one year for mechanic and electric parts, 3 years for electronic parts. Consumable parts as PTFE covers, felts and silicone rubber are excluded from the warranty.

Warranty and liability for personal injury are excluded in case of:

- Improper operation and/or maintenance of the machine
- Operation of the machine with defective or non-functioning safety and protective devices.

- Operation of the machine with broken or not fully functional parts and assemblies.
- Failure to follow the instructions in detail
- Unauthorized modifications or changes to the machine
- Improper repair
- Acts of God or vandalism
- Unauthorized changes and modifications on machines and machine systems, in particular to control, mechanical, hydraulic or pneumatic components.

The above will also lead to cancellation of our EG declaration of conformity and the loss of the CE mark.

SPECIAL WARNINGS AND SPECIAL INFORMATIONS

In the manual will be indicated the following designations :

DANGER !



Denotes an imminent hazard.

To disregard this warning may result in death or serious injury.

CAUTION !



Indicates a potentially hazardous situation.

To ignore this advice could result injury.

WARNING !



Indicates a potentially hazardous situation. To disregard this notice may result of minor injuries.

NOTE !



Special instructions and prohibitions to prevent damage

SECURITY – AVOIDING HAZARDS

PROPER USE

- The heat presses Transmatic TS3P / TS5P / TS5 PA are exclusively designed to be used to print on textiles as well as subarticles as T-Shirts, Sweaters, Flag fabrics, Mousepad etc. Any other use is considered improper ! The supplier will not be liable of damages resulting from improper use. The risk lies entirely by the user.
- Before using the heat presses Transmatic TS3P/ TS5P/ TS5PA outside the above range of application, the customer service is to be consulted. Anything to the contrary of this eliminates warranty.
- The intended use includes the observance of the operating and maintenance instructions and the regular service of the machine.
- The heat presses have to be used and maintained only by trained persons.
- The heat presses have to be used only with original accessories and spare parts.

NOTE !



Wrong use could cause injury or hinderance to:


- body and life
- objects
- efficient use of the machine

DANGER SOURCES ACCIDENT PREVENTION

SOURCES OF DANGER

The heat transfer press of the type series TRANSMATIC TS3P /TS5P/TS5PA is built as a state of the art and the recognized safety-related rules and regulations. Compliance with the relevant safety and accident prevention regulations is required.

Nevertheless, there are the following residual risks :



WARNING !



The temperature of the heating plate (2) ranges from 20°C to 250°C. Do not touch the hot plate.

WARNING!



Risk of crushing by the movement of the heating plate.

Do not keep fingers and hands between the work top and the hot plate or between the area where the heat plate meets the cylinder as well near to the radius of the movement.

SAFETY DEVICES

CAUTION !



- Never remove or modify safety devices.
- Do not operate the machine if safety devices are not working correctly.

EMERGENCY STOP BUTTON



Pressing the emergency stop button only raises the hot plate. Voltage and compressed air supply is not interrupted. Risk of accident !

PERSONAL PROTECTIVE EQUIPMENT

Not required.

CE-MARK

The heat presses Transmatic TS3P / TS5P/TS5PA has been built in accordance with all relevant EU standards and is fitted with the CE mark.




The attached declaration of conformity loses its validity when the machines are altered or changed without our consent.

TECHNICAL DATA

| MOD. | TS 3 P | TS 5 P | TS 5 PA |
|-----------------------------|---|--------------|--------------|
| Working surface | 50 x 40 cm | | |
| Voltage | 230 V | | |
| Consumption | 2,2 kW | 2,2 kW | |
| Consumption p/hour | 0,1 kW / h | 0,1 kW / h | |
| Recommanded fuses (main) | 16 A | | |
| Fuse (devise) | FF 16 A | | |
| Regulable temperature | 20 °C bis 250 °C | | |
| Regulable Press time | 0 bis 999,9 s | | |
| Pressure | 0 bis 800 g / cm ² | | |
| Diameter of piston | min. 50 l | | |
| Volume of the compressor | 3bar =0,3 kg/cm ² 4 bar = 0,4 kg/cm ² 5 bar= 0,5 kg/cm ² 6 bar = 0,6 kg/cm ² | | |
| Pressure kg/cm ² | 6 bar (G 1/4“) | | |
| Piston power | 70 / 90 kg | 116 / 140 kg | 100 / 150 kg |

INSTALLATION

WORKSTATION



Place the heat press on a sturdy work table.

Set up the press with the feet (1) Make sure that it is resting flat and not wobbling.

WARNING !



The working table has to be aligned and be strong enough to support the weight of the press. The movement of the head of the press may move the machine. It is recommended to fasten the feet to the table.

INSTALLATION AND ASSEMBLY

Remove the packing.

Check the machine after unpacking and setting on the table. Check to be sure there are no obvious defects.

ELECTRICAL CONNECTION

Check, that the power switch of the machine is switched off.

Insert the plug into the socket (230 V)

WARNIG!




Connect the cable in a manner to avoid tripping hazards

PNEUMATIC CONNECTION

DANGER!



Connection to the pneumatic hose will cause the heat plate to raise up immediately. Risk of Accident !



Connect the hose to the pneumatic air supply (1) Slide valve to " ON " Position

ADVISE:

Regulation of the air pressure see capt. 6.4.2


WARNING!




Connect the pneumatic hose and cables in a way to avoid tripping hazards

FEATURES OF THE MACHINE


TS3P/TS5P/TS5PA




1. General Switch On/Off
2. Speed regulator (Regulates the speed of opening of the plate)
3. Fuse
4. Main Cable
5. Heat plate plug
6. Pressure regulation (In- coming pressure)
7. Maintenance unit
8. Slide valve
9. Compressed air supply
10. Pressure regulator (Working pressure)
11. Quick release lever of the working plate
 - Automatic opening
 - High productivity
 - Pre-press Funtion
 - Easy exchangeable underplates
 - Strong and rugged design for industrial use



TS 3 P




Detail "A"



1. Working plate with Nomex cover
2. Lever to change the top plate
3. Automatic Closing by pressing of 2 buttons
4. 2 Handles
5. Display
6. Emergency Stop
7. Guide
8. Heating plate with PTFE cover
9. Feet
10. Micro switch

TS 5 PA



1. 2 working plates with nomex cover
2. easy release lever
3. filter assembly
4. display
5. emergency stop
6. guide
7. heating plate with PTFE cover
8. adjustable feet
9. foot pedal


START UP

NOTICE !



- Electrical Plug must be inserted
- Compressed air should be connected
- Press must stand firm and level
- Place main switcher to position 1.

INSTRUCTION TOUCH SCREEN




SETPOINT SETTINGS

Follow the indications of your transfer paper manufacturer. To change temperature setting, touch box 1 digit the new value and press enter to store.

The first value on the display (*) shows you the real temperature on the heating plate, the second value (**) shows the set temperature.


The machine is ready to press when both values are the same.

Temperature alarm is activated until heating does not reach the set temperature.



SETTING TIMER

To change timer settings press on box 2 , use fingerboard to write in the new value – press enter to store.



RESET PIECE COUNTER

on the main MENU touch this box




Touch here to reset the counter




PS: It is not possible to reset the historical value.

SUBMENU TOUCH SCREEN

Touching MENU  you login the submenu




INPUT/OUTPUT PLC





SETTING AND CHANGE OF SETPOINTS PRESET

You may create 4 customized presetting's. Press " Cycle set "  to activate or change a preset.



1. CHANGE PRESET

- Touch arrow  to enter the menu
- Set requested setpoints





Set 2 °C: Underplaten Heating if machine with this option

Type: Name of Preset
Press here to change name of the preset.

Preheating
Remember to activate Quantities of timers(see page 16)

2. ACTIVATE PRESET

To activate Preset press on the number of the program 

- Control on the main menu  if the program is activated.

- Control that the pressure is the same than The preset (If the box light yellow – the pressure is $> < 0,3$ bar respect of the set value)(see page 19 for change pressure)



Preset pressure

Real pressure

SETTING QUANTITY OF TIMERS (ADD PREHEATING)


Touch “ Main set ” to increase quantities of the timers.



Touch symbol to activate:

1 : timer for the pressing time

2 : timer for the pressing time and timer for the preheating/ironing of the material before printing



OPTION : ACTIVATE AUTOMATIC START (ONLY TS5PA)

1)Activate WAIT TIMER

2)Select waiting time between one and another print

3)Control , on the main menu If the program is active




4)Once the program is active – press the start pedal -

5)From this moment the machine works automatically




In case of emergency press the emergency stop



REGULATION OF THE PRESSURE

OPERATING PRESSURE

Set the operating pressure on the knob (1) of the maintenance unit. Pull the knob up until the yellow ring is visible. Set the maximum Pressure. The display on the gauge (2) should show 5 to 8 bar. Press the knob again until the yellow ring is no longer visible.




PRESSURE

Regulate the cylinder pressure with the regulator on the opposite side of the machine. Pull out the knob until you can see the yellow ring.

- Turning to the + direction you increase the pressure
- Turning to the – direction you decrease the pressure

The pressure can be adjusted between min. 1.5 bar and a maximum of 6 Bar.

After the setting of the value you have to push the controller until the 'yellow ring is no longer visible.



ADVISE!

The regulated pressure is indicated on the display only when the heat plate is pressing. Change or correct the value until you reach the desired pressure.

The display reacts a little slow and can change sometimes if the machine stands still.


BACK PRESSURE OPTION

Machines equipped with back pressure: You have to set the desired pressure on the pressure gauge located on the right of the machine (we recommend a minimum pressure of 4 bar) Subsequently pressure has to be set on the pressure gauge on the left side of the machine back pressure (for example 2 bar). At this point the pressure setting on the plate is set on 2 bar effective

The back pressure must be inserted in the case you need to apply transfers on a very high floor or to prevent marks on the material to be printed. We suggest to put the pressure to 0 in the case of using transfers of common use.

SELECT THE SPEED OF THE PISTON

You can regulate the speed of piston on the speed regulator (1) on the back of the machine.




CAUTION !





Take care of the temperature of the working plate if you want to change it during the operation.

1. Swing both of the quick- release levers und the working plate (1) for 180°.
2. Withdraw the plate (if you want to change the silicon rubber for example)



1. When re-installing the countertop make sure the the mounting holes (3) of the working plate are placed correctly to the locking pins of the holder.
2. Swing the quick – release levers once again for 180 ° to the old position. The plate is locked.




MAINTENANCE, CARE AND CLEANING

DAILY AND AS NEEDED


After work, clean the PTFE cover of possible adhesive residue, with a soft and clean cloth.

MONTHLY

- Check the PTFE covering the hot plate. If the PTFE cover is torn or damaged it must be replaced.
- Check the nomex cover and the silicon rubber on the bottom plate. Change the cover if it is damaged. If the silicon rubber has no indentations or high and low spots, it should also be replaced.



- After switching off the pressure and any collected moisture will drain out alone.




6 MONTHS

- Test the effective temperature on the plate using a temperature strip. If the real temperature is lower or higher please increase the temperature on the display accordingly.

YEARLY

- Electrical testing in accordance with accident prevention
- Check if joints are moving smoothly, oil or grease with ordinary bearing grease.
- Grease guide rod (1) and locking pins with normal grease.




HOW TO CHANGE THE PTFE COVER

If the PTFE cover is damaged it has to be replaced. Switch off the machine and make sure that the heating plate is cold. Unscrew the 4 screws (1) and you loose the 2 rods holding the teflon sheet. Change the PTFE cover and punch 4 little holes in the PTFE textiles in order to fix again the teflon as before.

ADVICE!




On the 2 rods there are 2 threadend pins which fits into the screws.



CHANGING THE ACCESSORY

To change out the flat working plate with an cap accessory:




1. Unscrew the Allen screw. (2)
2. Change the plate together with its base.(1)
3. Align the hole of the punch (3) to the bolt position.
4. Tighten the allen screw very firmly.



TROUBLE SHOOTING

If your press does not work as intended, the following table will help you in troubleshooting

| ERROR | CAUSE | CORRECTION |
|--|---|---|
| Main switch light is not lit | <ul style="list-style-type: none"> • Bulb defect • Cable defect | Replace the defective part |
| Heat plate does not shut down | <ul style="list-style-type: none"> • Board defect • Valve defect • Start button defect • Hand security def. | Replace the defective part |
| TS5PA: Heat plate does not move and turn | <ul style="list-style-type: none"> • Relais defect • Valve defect • Bipolare Cable defect | Replace the defective part |
| Heating plate falls down by its own weight | <ul style="list-style-type: none"> • No air connection | Check the air connection |
| Heat plate opens during pressing | <ul style="list-style-type: none"> • Sensor defect • Sensor is moved | Replace the sensor Regulate position of the sensor |
| Alarm Temperatur | <ul style="list-style-type: none"> • Relay defect • Board defect | Replace the defective part |
| Alarm Sonda | <ul style="list-style-type: none"> • Heat Feeler defect | |
| Alarm Pressure | <ul style="list-style-type: none"> • No Air on the line | |
| Heat plate is not heating | <ul style="list-style-type: none"> • Fuse is burned • Relay defect • Heating element is burned | Change the fuse or replace the defective part |
| Air comes out of the piston | <ul style="list-style-type: none"> • Valve defect • Piston defect | Replace the defective part |
| Piston comes down slowly | <ul style="list-style-type: none"> • Shock absorbers is dirty or blocked | Replace the defective part |
| Display is not lighting | <ul style="list-style-type: none"> • Error on the board • Cable between board and display defect | Replace the defective part |
| Hand security if not working | <ul style="list-style-type: none"> • Board defect | Replace the part |
| Main switch light is not lit | <ul style="list-style-type: none"> • Bulb defect • Cable defect | Replace the defective part |

| ERROR | CAUSE | CORRECTION |
|---|---|--|
| Switching on the Machine – machine not react | <ul style="list-style-type: none"> • The plug is not well in • There is no electricity on the line • Fuse broken | <ul style="list-style-type: none"> • Insert the plug • Control the line • Change the fuse  |
| Heating plate is not parallel to the underplate | <ul style="list-style-type: none"> • The mechanic stop moved • The allen is unscrewed | <p>1. Regolate the stop</p>  <p>2. Tighten the allen strongly</p>  |

SPARE PARTS


Ordering spare parts or asking for a technical assistance.

ADVISE!



The machine number and the year of construction are always to be communicated before asking for assistance.

You find the serial number (1) on the back of the base.




DISPOSAL



This product may not be released to the normal disposal at the end of it's life.


Transmatic Srl
Via E. Ferrari 9/11/13 20020 Lazzate (MI) Italy
Tel +39 02 96329816 / +39 02 96728422 fax
info@transmaticsrl.com

SPARE PARTS MOD. TS2P




| POS. | COD. | DESCRIZIONE |
|------|------------|------------------------|
| 01 | A 1051 | BASAMENTO |
| 02 | A 510 | PERNO CON DISCO |
| 03 | P 107 | PISTONE |
| 04 | A 1052 | CARTER COPRI GUIDE INF |
| 05 | A 405(36) | COPERTINA |
| 06 | A 505(50) | COPERTINA |
| 07 | A 508 | STAFFE DX SX |
| 08 | A 205 | CARTER STRUM. |
| 09 | C 807 | PERNO PRESSIONE |
| 10 | P 133 | GRUPPO F.R.L. |
| 11 | P 113 | VAL. MANICOTTO |
| 12 | P 183 | REG. PRESSIONE |
| 13 | P 185 | ELET. VALVOLA |
| 14 | P 181 | MICRO MAGNETICO |
| 15 | P 204 | BOBINA 24V |
| 16 | A 1053 | CARTER COPRIGUIDE SUP. |
| 17 | C 605 | PRESSACAVO |
| 18 | A 544 | SUP. TAV. MOLL. |
| 19 | C 889 | GUIDE TELESCOPICHE |
| 20 | P 125 | REG. VELOCITA' |
| 21 | A 1039(38) | PIASTRA TERMICA |
| 22 | A 1040(50) | PIASTRA TERMICA |
| 23 | C 104 | BACCHETTA TEFLON |
| 24 | B 992 | TOUCHSCREEN MAGELIS |
| 25 | S 060 | PT 100 |
| 26 | C 102(36) | TEFLON |
| 27 | C 103(50) | TEFLON |
| 28 | C 201(36) | SILICONE |
| 29 | C 202(50) | SILICONE |
| 30 | A 101(36) | TAV. MOLL. |
| 31 | A 201(50) | TAV. MOLL. |
| 32 | C 116-05 | PIEDINO |
| 33 | A 967 | MOLLA LEVA7BLOCCO |
| 34 | S 194 | RELE' STATICO 25A |
| 35 | C 647-05 | PORTA FUSIBILE |
| 36 | B 113 | INTERUTTORE |
| 37 | S 507 | CONNETTORE FEMMINA |
| 38 | B 809 | PULS. START |
| 39 | B 993 | CPU SCH.TM221CE16T |
| 40 | B 810-05 | STOP A FUNGO |
| 41 | A 245 | SUPP. INTERCAMBIABILE |
| 42 | C 150-05 | LEVA BLOCCO P.INT. |
| 43 | C 648-16 | FUSIBILE |
| 44 | C 576 | MANIGLIA SPOSTAM. |
| 45 | A 546 | VOLANTINO TAV. MOLL. |
| 46 | P 110 | MANOMETRO |
| 47 | B 995 | SWITCHING 2.5A 24V |
| 48 | C 766 | SUPPORO MICRO |
| 49 | S 318 | PRESSOSTATO |
| | C 768 | SUPPORO MAGNETE |
| | A 965 | SUPP. LEVA/BLOCCO |
| | A 966 | LEVA BLOCCO P.INT. |
| | S 508 | CONNETTORE MASCHIO |
| | S 509 | FRONT.LEXAN TOUCHSC. |

SPARE PARTS MOD. TS3P




| POS. | COD. | DESCRIZIONE |
|------|------------|-----------------------|
| 01 | A 401 | BASAMENTO |
| 02 | A 510 | PERNO CON DISCO |
| 03 | P 107 | PISTONE |
| 04 | C 106-05 | BRACCIO |
| 05 | A 405(36) | COPERTINA |
| 06 | A 505(50) | COPERTINA |
| 07 | A 508 | STAFFE DX SX |
| 08 | A 205 | CARTER STRUM. |
| 09 | C 807 | PERNO PRESSIONE |
| 10 | P 133 | GRUPPO F.R.L. |
| 11 | P 113 | VAL. MANICOTTO |
| 12 | P 183 | REG. PRESSIONE |
| 13 | P 185 | ELET. VALVOLA |
| 14 | P 181 | MICRO MAGNETICO |
| 15 | P 204 | BOBINA 24V |
| 16 | C 119-05 | CUSCINETTI |
| 17 | C 605 | PRESSACAVO |
| 18 | A 544 | SUPP. TAV. MOLL. |
| 19 | C 120 | GHIERE |
| 20 | P 125 | REG. VELOCITA' |
| 21 | A 1039(38) | PIASTRA TERMICA |
| 22 | A 1040(50) | BACCHETTA TEFLON |
| 23 | C 104 | TOUCHSCREEN MAGELIS |
| 24 | S 060 | PT 100 |
| 25 | C 102(36) | TEFLON |
| 26 | C 103(50) | TEFLON |
| 27 | C 201(36) | SILICONE |
| 28 | C 202(50) | SILICONE |
| 29 | A 101(36) | TAV. MOLL. |
| 30 | A 201(50) | TAV. MOLL. |
| 31 | C 116-05 | PIEDINO |
| 32 | A 967 | MOLLA LEVA7BLOCCO |
| 33 | S 194 | RELE' STATICO 25A |
| 34 | C 647-05 | PORTA FUSIBILE |
| 35 | B 113 | INTERUTTORE |
| 36 | S 507 | CONNETTORE FEMMINA |
| 37 | B 809 | PULS. START |
| 38 | B 993 | CPU SCH.TM221CE16T |
| 39 | B 810-05 | STOP A FUNGO |
| 40 | A 245 | SUPP. INTERCAMBIABILE |
| 41 | C 150 | LEVA BLOCCO P.T.\ST. |
| 42 | C 648-16 | FUSIBILE |
| 43 | C 576 | MANIGLIA SPOSTAM. |
| 44 | A 546 | VOLANTINO TAV. MOLL. |
| 45 | S 318 | PRESSOSTATO |
| 46 | B 995 | SWITCHING 2.5A 24V |
| 47 | C 766 | SUPPORO MICRO |
| 48 | C 767 | MAGNETE |
| 49 | A 965 | SUPPORO MAGNETE |
| 50 | A 966 | SUPP. LEVA/BLOCCO |
| | S 508 | LEVA BLOCCO P.INT. |
| | S 509 | CONNETTORE MASCHIO |
| | | FRONT.LEXAN TOUCHSCR. |

SPARE PARTS MOD. TS5P








| POS. | COD. | DESCRIZIONE |
|------|------------|--------------------------|
| 01 | A 401 | BASAMENTO |
| 02 | A 510 | PERNO CON DISCO |
| 03 | P 107 | PISTONE |
| 04 | C 106-05 | BRACCIO |
| 05 | A 405(36) | COPERTINA |
| 06 | A 505(50) | COPERTINA |
| 07 | A 508 | STAFFE DX SX |
| 08 | A 205 | CARTER STRUM. |
| 09 | C 807 | PERNO PRESSIONE |
| 10 | P 133 | GRUPPO F.R.L. |
| 11 | P 113 | VAL. MANICOTTO |
| 12 | P 183 | REG. PRESSIONE |
| 13 | P 185 | ELET. VALVOLE |
| 14 | P 181 | MICRO MAGNETICO |
| 15 | P 204 | BOBINA 24V |
| 16 | C 119-05 | CUSCINETTI |
| 17 | A 544 | PRESSACAVO |
| 18 | C 605 | SUPP. TAV. MOLL. |
| 19 | C 120 | GHIERE |
| 20 | P 125 | REG. VELOCITA' |
| 21 | A 1039(38) | PIASTRA TERMICA |
| 22 | A 202(50) | PIASTRA TERMICA |
| 23 | C 104 | BACCHETTA TEFLON |
| 24 | B 993 | CPU SCHNEIDER TM221CE16T |
| 25 | S 060 | PT100 |
| 26 | C 102(36) | TEFLON |
| 27 | C 103(50) | TEFLON |
| 28 | C 201(36) | SILICONE |
| 29 | C 202(50) | SILICONE |
| 30 | A 101(36) | TAV. MOLL. |
| 31 | A 201(50) | TAV. MOLL. |
| 32 | C 116-05 | PIEDINO |
| 33 | A 967 | MOLLA LEVA7BLOCCO |
| 34 | S 194 | RELE' STATICO 25A |
| 35 | C 647-05 | PORTA FUSIBILE |
| 36 | B 113 | INTERUTTORE |
| 37 | S 507 | CONNETTORE FEMMINA |
| 38 | B 809 | PULS. START |
| 39 | B 992 | TOUCHSCREEN MAGELIS |
| 40 | B 810-05 | STOP A FUNGO |
| 41 | A 245 | SUPP. INTERCAMBIABILE |
| 42 | C 150-05 | LEVA BLOCCO P.I.\ST. |
| 43 | C 648-16 | FUSIBILE |
| 44 | C 576 | MANIGLIA SPOSTAM. |
| 45 | A 546 | VOLANTINO TAV. MOLL. |
| 46 | P 110 | MANOMETRO |
| 47 | B 995 | SWITCHING 2.5A 24V |
| 48 | C 766 | SUPP. MICRO |
| 49 | C 768 | PRESSOSTATO |
| 50 | A 965 | SUPP. MAGNETE |
| 51 | A 966 | SUPP. LEVA/BLOCCO |
| 52 | A 966 | LEVA BLOCCO P.INT. |
| 53 | S 508 | CONNETTORE MASCHIO |
| 54 | S 509 | FRONT.LEXAN TOUCHSC. |

MOD. TS5PA



| POS. | COD. | DESCRIZIONE |
|------|------------|--------------------------|
| 01 | A 401 | BASAMENTO |
| 02 | A 510 | PERNO CON DISCO |
| 03 | P 107 | PISTONE |
| 04 | C 106-05 | BRACCIO |
| 05 | A 405(36) | COPERTINA |
| 06 | A 505(50) | COPERTINA |
| 07 | A 508 | STAFFE DX. SX |
| 08 | A 205 | CARTER STRUM. |
| 09 | C 807 | PERNO PRESSIONE |
| 10 | P 133 | GRUPPO F.R.L. |
| 11 | P 113 | VAL. MANICOTTO |
| 12 | P 183 | REG. PRESSIONE |
| 13 | P 185 | ELET. VALVOIA |
| 14 | P 181 | MICRO MAGNETICO |
| 15 | P 204 | BOBINA 24V |
| 16 | C 119-05 | CUSCINETTI |
| 17 | C 605 | PRESSACAVO |
| 18 | A 544 | SUPP. TAV. MOLL. |
| 19 | C 120 | GHIERE |
| 20 | P 125 | REG. VELOCITA' |
| 21 | A 1039(38) | PIASTRA TERMICA |
| 22 | A 1040(50) | PIASTRA TERMICA |
| 23 | C 104 | BACCHETTA TEFLON |
| 24 | B 993 | CPU SCHNEIDER TM221CE16T |
| 25 | S 060 | PT100 |
| 26 | C 102(36) | TEFLON |
| 27 | C 103(50) | TEFLON |
| 28 | C 201(36) | SILICONE |
| 29 | C 202(50) | SILICONE |
| 30 | A 101(36) | TAV. MOLL. |
| 31 | A 201(50) | TAV. MOLL. |
| 32 | C 116-05 | PIEDINO |
| 33 | A 967 | MOLLA LEVA7BLOCCO |
| 34 | S 194 | RELE' STATICO 25A |
| 35 | C 647-05 | PORTA FUSIBILE |
| 36 | B 113 | INTERUTTORE |
| 37 | S 505 | CONNETTORE FEMMINA |
| 38 | B 809 | PULS. START |
| 39 | B 992 | TOUCHSCREEN MAGELUS |
| 40 | B 810-05 | STOP A FUNGO |
| 41 | A 245 | SUPP. INTERCAMBIABILE |
| 42 | C 150-05 | LEVA. BLOCCO P.T./ST. |
| 43 | C 648-16 | FUSIBILE |
| 44 | C 576 | MANIGLIA SPOSTAM. |
| 45 | A 546 | VOLANTINO TAV. MOLL. |
| 46 | A 230 | BARRIERA SICUREZZA |
| 47 | B 995 | SWITCHING 2.5A 24V |
| 48 | C 766 | SUPP. MICRO |
| 49 | S 318 | PRESSOSTATO |
| 50 | C 768 | SUPP. MAGNETE |
| 51 | A 965 | SUPP. LEVA/BLOCCO |
| 52 | A 966 | LEVA BLOCCO P.INT. |
| 53 | S 506 | CONNETTORE MASCHIO |
| 54 | S 509 | FRONT.LEXAN TOUCHSC. |

SPARE PARTS MOD. TS5 PA



| POS. | COD. | DESCRIZIONE |
|------|-------|---------------------|
| 01 | P 171 | FORCELLA CIL. |
| 02 | P 141 | CILINDRO SPOST. |
| 03 | P 145 | ELETTROVALVOLA |
| 04 | P 111 | GRUPPO F.L.R. |
| 05 | P 113 | VALVOLA MANICOTTO |
| 06 | A 231 | SUPP. BARRIERA SIC. |
| 07 | A 230 | BARRIERA SICUREZZA |
| 08 | P 181 | MICRO MAGNETICO |
| 09 | P 204 | BOBINA 24V |
| 10 | A 229 | CARTER CIL. MOVIM. |
| 11 | B 136 | PEDALE START |

TABELLA RIASSUNTIVA
QUADRO ELETTRICO


| | |
|----------------------------|------|
| TENSIONE NOMINALE | 400V |
| FREQUENZA | 50HZ |
| POTENZE E CORRENTI: | |
| | |
| LINEE ALIMENTAZIONE | |
| 400V | |
| STRUTTURA DEL QUADRO | |
| GRADO DI PROTEZIONE MINIMO | IP55 |


| | |
|---|--|
| TABELLA COLORI CAVI ALL'INTERNO QUADRO ELETTRICO COULOR TABLE FOR CABLES INSIDE ELECTRIC BOARD | |
| COLORE FILO WIRE COLOUR | DESCRIZIONE DESCRIPTION |
| NERO BLACK | CIRCUITI DI POTENZA POWER CIRCUITS |
| ROSSO RED | CIRCUITI COMANDO AUSILIARI A.C. AC AUXILIARY CONTROL CIRCUITS |
| GIALLO-VERDE YELLOW-GREEN | CONDUTTORI PROTEZIONE A TERRA EARTH WIRES |

| | | | |
|---|--|------------------------------------|----------------|
| LEGENDA LETTURA SCHEMA DIAGRAM READYNG KEY | | | |
| SIGLA COMPONENTI COMPONENTS INITIALS | | N°FILO WIRE N° | |
| ESEMPIO EXAMPLE | | ESEMPIO EXAMPLE | |
| KA1.1 | | 1.1 | |
| TIPO N°PAGINA PROGRESSIVO TYPE PAGE N° PROGRESSIVE | | N°PAGINA SCHEMA DIAGRAM PAGE N° | N°FILO WIRE N° |

| | | | | |
|--------------------|--------|-----------------|-----------|--------------------|
| TENSIONE ESERCIZIO | 400V | PROTEZIONE IP55 | NORME | CE |
| TENSIONE COMANDI | 24V DC | | | |
| TENSIONE SEGNALI | | | | |
| | | | | |
| | | | | |
| | | | | TRANSMATIC |
| | | | | MOD.TS2P TS3P TS5P |
| | | | | TS5PA 74P 100/70 |
| 25/01/16 | AP | | PAGE | 0/18 |
| DATA | FIRMA | | NEXT PAGE | 1 |

GENERAL SWITCH QS1.1 3x





25/01/16

DATA

AP

FIRMA

TRANSMATIC

COMPOSIZIONE PLC

MOD.TS2P TS3P

PAGE

2/4

NEXT PAGE

3

8

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---|---|---|---|---|---|---|---|



| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---|---|---|---|---|---|---|---|

LEGEND MOD.TS2P TS3P

| TIPO TYPE | N°PAG. PAGE N° | PROG. SEQ. | DESCRIZIONE DESCRIPTION | TIPO TYPE | N°PAG. PAGE N° | PROG. SEQ. | DESCRIZIONE DESCRIPTION |
|--------------|-------------------|---------------|--------------------------------|--------------|-------------------|---------------|----------------------------|
| QS | 1 | .1 | POWER SWITCH | | | | |
| U | 1 | .1 | SWITCHING 2.5A 24V | | | | |
| GS | 2 | .1 | S. STATIC RELAY 25A | | | | |
| FU | 2 | .1 | FUSE 12.5A | | | | |
| CN | 1 | .1 | CONNETTORE | | | | |
| PT | 1 | .1 | PT100 TERMORESISTENZA | | | | |
| RES | 1 | .1 | HEAT PLATE | | | | |
| OP | 2 | .1 | TOUCHSCREEN MAGELIS | | | | |
| CPU | 2 | .1 | CPU SCHEIDER TM221CE16T | | | | |
| MOD | 2 | .1 | MOD. TMC2T12 ANALOG IN | | | | |
| SA | 2 | .1 | P. START SWITCH | | | | |
| SB | 1 | .1 | STOP SWITCH | | | | |
| MS | 2 | .1 | F.C. PRESS UP | | | | |
| MS | 2 | .2 | F.C. PRESS DOWN | | | | |
| MS | 2 | .3 | F.C. PRESS RIGHT | | | | |
| MS | 2 | .4 | F.C. PRESS LEFT | | | | |
| SP | 2 | .1 | DIGITAL PRESSOSTAT | | | | |
| YV | 2 | .1 | BOBINVE03-E-S-6-24V E.V. PRESS | | | | |
| YV | 2 | .2 | BOBINVE03-E-S-6-24V E.V. RIGHT | | | | |
| YV | 2 | .3 | BOBINVE03-E-S-6-24V E.V. LEFT | | | | |
| CL | 3 | .1 | CIL.52M-50-20-160 | | | | |
| CL | 3 | .2 | CIL.COD 1200 | | | | |
| RV | 3 | .1 | REG.SPEED 7718/0813 | | | | |
| RV | 3 | .2 | REG.SPEED 7718/0813 | | | | |
| RV | 3 | .3 | REG.SPEED 7718/0813 | | | | |
| RV | 3 | .4 | REG.SPEED 7718/0813 | | | | |
| EV | 3 | .1 | VGD15-ER-ER-5 | | | | |
| EV | 3 | .2 | VGD15-EA-S-5 | | | | |
| RP | 3 | .1 | MINI REG 06P | | | | |
| FR | 3 | .1 | AIR PREP 20 CG | | | | |

TABELLA RIASSUNTIVA
QUADRO ELETTRICO


| | |
|----------------------------|------|
| TENSIONE NOMINALE | 400V |
| FREQUENZA | 50HZ |
| POTENZE E CORRENTI: | |
| LINEE ALIMENTAZIONE | 400V |
| STRUTTURA DEL QUADRO | |
| GRADO DI PROTEZIONE MINIMO | IP55 |


| | |
|---|--|
| TABELLA COLORI CAVI ALL'INTERNO QUADRO ELETTRICO COULOR TABLE FOR CABLES INSIDE ELECTRIC BOARD | |
| COLORE FILO WIRE COLOUR | DESCRIZIONE DESCRIPTION |
| NERO BLACK | CIRCUITI DI POTENZA POWER CIRCUITS |
| ROSSO RED | CIRCUITI COMANDO AUSILIARI A.C. AC AUXILIARY CONTROL CIRCUITS |
| GIALLO-VERDE YELLOW-GREEN | CONDUTTORI PROTEZIONE A TERRA EARTH WIRES |

| | | | |
|---|------------------------------------|-------------------|--|
| LEGENDA LETTURA SCHEMA DIAGRAM READING KEY | | | |
| SIGLA COMPONENTI COMPONENTS INITIALS | | N°FILO WIRE N° | |
| ESEMPIO EXAMPLE | | ESEMPIO EXAMPLE | |
| KA1.1 | | 1.1 | |
| / / | | / / | |
| TIPO N°PAGINA PROGRESSIVO TYPE PAGE N° PROGRESSIVE | N°PAGINA SCHEMA DIAGRAM PAGE N° | N°FILO WIRE N° | |


| | | | | |
|--------------------|--------|-----------------|--------------------|------|
| TENSIONE ESERCIZIO | 400V | PROTEZIONE IP55 | NORME | CE |
| TENSIONE COMANDI | 24V DC | | | |
| TENSIONE SEGNALI | | | | |
| | | | TRANSMATIC | |
| | | | MOD.TS2P TS3P TS5P | |
| | | | TS5PA 74P 100/70 | |
| 25/01/16 | AP | | PAGE | 0/18 |
| DATA | FIRMA | | NEXT PAGE | 1 |

GENERAL SWITCH QS1.1 3x





| | | | | | | | |
|---|--|--|--|--|--|--|--|
| 1 | | | | | | | |
| 2 | | | | | | | |
| 3 | | | | | | | |
| 4 | | | | | | | |
| 5 | | | | | | | |
| 6 | | | | | | | |
| 7 | | | | | | | |
| 8 | | | | | | | |



LEGEND MOD.TS5P

| TIPO TYPE | N°PAG. PAGE N° | PROG. SEQ. | DESCRIZIONE DESCRIPTION | TIPO TYPE | N°PAG. PAGE N° | PROG. SEQ. | DESCRIZIONE DESCRIPTION |
|--------------|-------------------|---------------|--------------------------------|--------------|-------------------|---------------|----------------------------|
| QS | 1 | .1 | POWER SWITCH | | | | |
| U | 1 | .1 | SWITCHING 2.5A 24V | | | | |
| GS | 2 | .1 | S. STATIC RELAY 25A | | | | |
| FU | 2 | .1 | FUSE 12.5A | | | | |
| CN | 1 | .1 | CONNETTORE | | | | |
| PT | 1 | .1 | PT100 TERMORESISTENZA | | | | |
| RES | 1 | .1 | HEAT PLATE | | | | |
| OP | 2 | .1 | TOUCHSCREEN MAGELIS | | | | |
| CPU | 2 | .1 | CPU SCHNEIDER TM221CE16T | | | | |
| MOD | 2 | .1 | MOD. TMC2T12 ANALOG IN | | | | |
| SA | 2 | .1 | P. START SWITCH | | | | |
| SB | 1 | .1 | STOP SWITCH | | | | |
| MS | 2 | .1 | F.C. PRESS UP | | | | |
| MS | 2 | .2 | F.C. PRESS DOWN | | | | |
| MS | 2 | .3 | F.C. PRESS RIGHT | | | | |
| MS | 2 | .4 | F.C. PRESS LEFT | | | | |
| SP | 2 | .1 | DIGITAL PRESSOSTAT | | | | |
| YV | 2 | .1 | BOBINVE03-E-S-6-24V E.V. PRESS | | | | |
| YV | 2 | .2 | BOBINVE03-E-S-6-24V E.V. RIGHT | | | | |
| YV | 2 | .3 | BOBINVE03-E-S-6-24V E.V. LEFT | | | | |
| CL | 3 | .1 | CIL.52M-50-20-160 | | | | |
| CL | 3 | .2 | CIL.COD 1200 | | | | |
| RV | 3 | .1 | REG.SPEED 7718/0813 | | | | |
| RV | 3 | .2 | REG.SPEED 7718/0813 | | | | |
| RV | 3 | .3 | REG.SPEED 7718/0813 | | | | |
| RV | 3 | .4 | REG.SPEED 7718/0813 | | | | |
| EV | 3 | .1 | VGD15-ER-ER-5 | | | | |
| EV | 3 | .2 | VGD15-EA-S-5 | | | | |
| RP | 3 | .1 | MINI REG 06P | | | | |
| FR | 3 | .1 | AIR PREP 20 CG | | | | |

TABELLA RIASSUNTIVA
QUADRO ELETTRICO


| |
|------------------------------------|
| TENSIONE NOMINALE 400V |
| FREQUENZA 50HZ |
| POTENZE E CORRENTI: |
| |
| LINEE ALIMENTAZIONE 400V |
| STRUTTURA DEL QUADRO |
| GRADO DI PROTEZIONE MINIMO IP55 |

| | |
|---|--|
| TABELLA COLORI CAVI ALL'INTERNO QUADRO ELETTRICO COULOR TABLE FOR CABLES INSIDE ELECTRIC BOARD | |
| COLORE FILO WIRE COLOUR | DESCRIZIONE DESCRIPTION |
| NERO BLACK | CIRCUITI DI POTENZA POWER CIRCUITS |
| ROSSO RED | CIRCUITI COMANDO AUSILIARI A.C. AC AUXILIARY CONTROL CIRCUITS |
| GIALLO-VERDE YELLOW-GREEN | CONDUTTORI PROTEZIONE A TERRA EARTH WIRES |

| | | | |
|--|------------------------------------|--|-----------------------------------|
| LEGENDA LETTURA SCHEMA DIAGRAM READYNG KEY | | | |
| SIGLA COMPONENTI COMPONENTS INITIALS ESEMPIO EXAMPLE | KA1.1 | | N°FILO WIRE N° ESEMPIO EXAMPLE |
| TIPO N°PAGINA PROGRESSIVO TYPE PAGE N° PROGRESSIVE | N°PAGINA SCHEMA DIAGRAM PAGE N° | | N°FILO WIRE N° |

| | | | | |
|--|----------------|-----------------|--|------|
| TENSIONE ESERCIZIO TENSIONE COMANDI | 400V 24V DC | PROTEZIONE IP55 | NORME CE | |
| TENSIONE SEGNALI | | | | |
| | | | | |
| | | | TRANSMATIC | |
| | | | MOD.TS2P TS3P TS5P TS5PA 74P 100/70 | |
| 25/01/16 | AP | | PAGE | 0/18 |
| DATA | FIRMA | | NEXT PAGE | 1 |

GENERAL SWITCH QS1.1 3x



25/01/16

DATA

AP

FIRMA

TRANSMATIC

MOD.TSSPA

PAGE 1/4
NEXT PAGE 2

1

2

3


4

5

6

7

8




25/01/16
DATA
AP
FIRMA

TRANSMATTC
COMPOSIZIONE PLC

MOD.TSSPA

PNEUMATIC DIAGRAM



LEGEND MOD.TS5PA

[illegible]

